



Cyclorama
Harkness screen
Traveler

up to offices
down to dressingrooms

Ushers Station

Box Office

lobby

A ♿ 18 19 20 21 ♿

B 16 17 18 19 20 21 22 23 24

C 16 17 18 19 20 21 22 23 24 25 26

D 16 17 18 19 20 21 22 23 24 25 26 27

E 16 17 18 19 20 21 22 23 24 25 26 27 28

F 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30

G 16 17 18 19 20 21 22 23 24 25 26 27 28 29

31 32 33 34 35 36 37 38

31 32 33 34 35 36 37 38 39

31 32 33 34 35 36 37 38 39 40

31 32 33 34 35 36 37 38 39 40 41

31 32 33 34 35 36 37 38 39 40 41 42

31 32 33 34 35 36 37 38 39 40 41 42

31 32 33 34 35 36 37 38 39 40 41 42 43

Removeable sliding glass

Dimmer Board A/V Rack Audio Console Audio Rack

Control booth

loft ladder